



Nut mix

Recipe by V-ZUG Ltd.



Preparation	10 Mins
Cooking time	9 Mins
Portions	4
Appliance	CombairSteamer V2000 from 2021

caramelized nuts

Nuts

- 150 g sugar
- 150 ml water
- 200 g nuts (e.g. walnut kernels, cashew nuts, almonds, pecan nuts)

Nuts

Preheat the cooking space to 180 °C using the hot air mode.
Put all the ingredients in a pan and bring to the boil. Reduce the heat and simmer for 2 minutes.
Pour off the liquid and strain the nuts.
Spread the nuts over a lined baking tray and caramelize in the middle shelf position for 9 minutes.
Allow to cool.

Cooking steps

(Pre-)heat cooking space to 180 °C with Hot air
Preheating finished. Put the food in.
Hot air 180 °C for 9 Mins





Tips

Season the nuts with salt and spices to taste before or after toasting.

Accessories

Baking tray

Additional information

Created on 27.02.2023

